

Graphical display



Main features

- Graphical display with backlight
- Showing errors and limits by steady or flashing colours
- Fits Baumer CombiSeries™ (Ø80 mm FlexHousing)
- Hygienic design
- Option: Two configurable relay outputs
- Programmable by touch screen
- Easy and fully programmable with FlexProgrammer 9701
- ATEX
- UL

Applications

- Remote display fits for all 4 20 mA transmitter
- Wall mounting, panel mounting and pipe mounting











Technical Data	
Input	
Measuring range	3.523 mA (normal working range 420 mA)
Connections	2 screw terminals for loop power, signal 4 screw terminals for relay outputs
Accuracy	≤ ±0.1% of input span within -1070 °C ≤ ±0.2% of input span within -3010 °C / 7080 °C
Loop voltage drop	Two levels depending on chosen backlight brightness @ 20 mA: - Low bright backlight (<40%): Max. 4V @23 °C - High bright backlight (>40%): Max. 6.5V @23 °C
Sample time	≤ 1 second. Typical 0.3 second
Start-up time	≤ 5 second
User-configurable data	a
Measuring range	420 mA
Error/warning indication	Individually configurable display and backlight indication in white, green or red colour, steady or flashing light. Configurable limits between 3.5 and 23 mA
Zoom on range	Minimum 2 mA of input span
Damping	030 seconds
Linearization table	2 to 30 points
Measuring unit (standard selectable)	°C, °F, K bar, mbar, kPa, MPa, psi, kg/cm2, mmHg, mH2O, atm, "Hg, mHg, "H2O, %, I/h, Ton, m3, m3/h, Hz, mS, mV, V, ohm, Hz, sec, %, mA, or user defined (programmable with FlexProgrammer)
User defined unit	8 x 20 pixels matrix
Dec. point position	xxxxx, xxxx.x, xxx.xx, xx.xxx,

x.xxxx, .xxxxx, AUTO

Relay			
Contacts	2 solid state relays		
Voltage	60 Vp		
Load Current	75 mA		
Max On resistance	10 Ohm The built in relays are not activated as standard. They can be activated at purchase or SW activation code can be purchased later.		
Response time	0.6 s typ., with standard screen 1.5 s typ., with product specific screen		
Display			
Туре	FSTN Graphically LCD		
Measuring range	-999999999		
Digit height	Max. 22 mm		
EMC data			
Immunity	EN 61326		
Emission	EN 61326		
EMC immunity Influence	≤ ±1% of input FS		
Communication			
FlexProgrammer 2-way cor	mmunication for configuration.		
Test conditions			
Operating temperature	23°C ± 2 °C		
Compliance and approv	rals		
Approvals	cULus listed, E491206		
	IEC 61010-1:2010		
	IEC 61010-2-201:2013		

EN/2021-03-09 Design and specifications subject to change without notice



Graphical display

Technical Data	
Environmental cond	ditions
Optimal readability	-1070 °C
Operating temperature	-3080 °C
Storage temperature	-4085 °C
Humidity	max. 98% RH, condensing
Vibrations	IEC60068-2-6, test FC 25100 Hz, 4.0g DNV high vibration strain, class B 1.6mm, 225 Hz
Mechanical tolerances	ISO 2768-m
Mechanical data	
Dimensions	See dimensional drawing
Material	Polycarbonate plastic
Enclosure	FlexHousing and front ring stainless steel, AISI 304
Protection class	IP 10 on terminals


ATEX Gas ia and for A	TEX Dust	ia	
Approval Gas Zone 0/1 Dust Zone 20/2		G, Ex ia IIC T5 Ga D, Ex ia IIIC T100°C	; Da
Voltage drop	U_{Disp}	4.5 6.5 VDC	
Temperature class		Zone 0 and 20 Zone 1/2 and 21/2	-20 60 °C 22 -30 65 °C
Internal inductivity	L _i	<10 µH	
Internal capacity	C _i	<15 nF	
Barrier data	U _i I _i P _i	<30 VDC <0.1 A <0.75 W	

Mechanical data	
Dimensions	See dimensional drawing
Material	Polycarbonate plastic
Enclosure	FlexHousing and front ring stainless steel, AISI 304
Protection class	IP 10 on terminals IP 67 in FlexHousing
Weight	100 g - display alone 170 g - display incl. front ring 475 g - display in FlexHousing for wall mounting

ATEX Gas nA			
Approval Gas Zone 2	🐼 II 3 G, Ex nA II T5		
Voltage drop	U _{Disp}	4.5 6.5 VDC	
Temperature class	T1T5	-30 < T _{amb} < 65 °C	
Internal inductivity	L,	<10 µH	
Internal capacity	C _i	<15 nF	
Maximum voltage	U _{max}	<35 VDC	
Maximum current	l _{max}	<0.1 A	

Other data Temperature drift ≤ 0,001%/10K (inside optimal readability temperature range) ≤ 0,0015%/10K (outside optimal readability temperature range) Power up time ≤ 15 sec.

Electrical connections



Terminal 1 - Supply + Terminal 2 - Supply -

Terminal 3 - Relay 2 Terminal 4 - Relay 2

Terminal 5 - Relay 1


Terminal 6 - Relay 1

Programming

Connect the FlexProgrammer to the CombiView, DFON as per below.

Disposal of product and packing

According to national laws or by returning to Baumer.



It is not necessary to disconnect the power to the CombiView, DFON display

The FlexProgrammer 9701 is a dedicated tool to Configure all Baumer configurable products.



FlexProgrammer, No.: 9701.0001

The FlexProgrammer interface unit will be delivered complete

- CD with FlexProgram software
- Product drivers (DTM-files)
- cables

The CombiView, DFON can also be programmed by the touch bottoms on the display. Please see "Operating instructions for CombiView, DFON".

Page 2 / 5




Graphical display


Electrical connections

ATEX Gas ia and for ATEX Dust ia


Display in the zone, transmitter outside the zone




Display and transmitter in the zone 4 ... 20 mA



Display in the zone/transmitter outside the zone




Display and transmitter in the zone




ATEX Gas nA

Display without relay output



Display with relay output



Selectable views



Value Small / Large



Analog w. Bar graph / Value



Bar graph Vertical / horizontal



Tank illustration Tank / Bottle

Data sheet DFON

Visual alert



Status ok





Alert status



Graphical display

Drawings / Dimensions in mm






Mounting for stand alone instrument

Wall mounting, DFON-xxx2.2x



FlexHousing with Ø110 mm rear flange with 3 x Ø4 mm holes for screws






Panel mounting, DFON-xxx2.30





Ø110 mm front flange with 3 x Ø4 mm holes for screws






Pipe mounting, DFON-xxx2.4x / ...2.5x / ...2.6x






FlexHousing with pipe bracket for Ø38, Ø51, Ø64 mm stand pipe







CombiView DFON Graphical display



Accessories, Software for relays

Activation code for relays (for instruments with not activated relays) UnitCom ribbon cable (for retrofitting of DFON on AFIx and PFMx)

DFO-SW 11128715

Page 5 / 5